



ISOMETER® isoMED527

Insulation monitoring device for medical applications



Table of contents

1	General information.....	5
1.1	How to use the manual.....	5
1.2	Indication of important instructions and information.....	5
1.3	Service and Support.....	5
1.4	Training courses and seminars.....	5
1.5	Delivery conditions.....	5
1.6	Inspection, transport and storage.....	6
1.7	Warranty and liability.....	6
1.8	Disposal of Bender devices.....	6
1.9	Safety.....	7
1.10	Cybersecurity.....	7
2	Product description.....	8
2.1	Intended use.....	8
2.2	Device features.....	8
2.3	Product description.....	9
2.4	Functional description.....	9
2.4.1	Insulation fault R_F	10
2.4.2	IsoNAP measurement method.....	11
2.4.3	Connection monitoring L1/L2.....	11
2.4.4	Connection monitoring Functional Earth.....	11
2.4.5	Monitoring the IT system transformer.....	11
2.4.6	Delay times t_b , t , t_{ae} , t_{on} and t_{off}	12
2.4.7	Message assignments for the alarm relays.....	13
2.4.8	Self-test.....	13
2.4.9	Factory setting.....	13
2.4.10	Device error.....	13
2.4.11	Device identification.....	14
3	Dimensions, mounting and connection.....	15
3.1	Dimension Diagram.....	15
3.2	Mounting and removal.....	16
3.3	Connection.....	16
3.3.1	Connection properties.....	16
3.3.2	Connections overview.....	17
3.3.3	Wiring diagram isoMED527.....	17

4 Commissioning.....19

5 Operation.....20

5.1 Control panel..... 20

5.2 STATUS LED..... 21

5.3 Measured value display LEDs..... 21

5.4 ALARM LEDs..... 22

5.5 T/R button..... 22

5.6 Function ADDR..... 23

5.7 Function RESET..... 23

5.8 Function TEST..... 23

5.9 Function NFC..... 24

5.10 Function PROTECT..... 24

5.11 Menu settings isoMED527..... 25

6 Interfaces..... 28

6.1 RS-485 interface..... 28

6.2 NFC (Near Field Communication)..... 29

6.2.1 Function modules..... 29

6.2.2 Subsequent activation of function modules..... 30

7 Technical data..... 32

7.1 Factory setting isoMED527..... 32

7.2 Technical data..... 33

7.2.1 Connections..... 36

7.3 Standards and approvals..... 40

7.4 Ordering details..... 40

7.5 Change log..... 41

1 General information

1.1 How to use the manual



ADVICE

This manual is intended for qualified personnel working in electrical engineering and electronics! Part of the device documentation in addition to this manual is the enclosed supplement "Safety instructions for Bender products".



ADVICE

Read the operating manual before mounting, connecting and commissioning the device. Keep the manual within easy reach for future reference.

1.2 Indication of important instructions and information



DANGER

Indicates a high risk of danger that will result in death or serious injury if not avoided.



WARNING

Indicates a medium risk of danger that can lead to death or serious injury if not avoided.



CAUTION

Indicates a low-level risk that can result in minor or moderate injury or damage to property if not avoided.



ADVICE

Indicates important facts that do not result in immediate injuries. They can lead to malfunctions if the device is handled incorrectly.



Information can help to optimise the use of the product.

1.3 Service and Support

Information and contact details about customer service, repair service or field service for Bender devices are available on the following website: <https://www.bender.de/en/service-support>.

1.4 Training courses and seminars

Regular face-to-face or online seminars for customers and other interested parties:

<https://www.bender.de/en/know-how/seminars>

1.5 Delivery conditions

The conditions of sale and delivery set out by Bender GmbH & Co. KG apply. These can be obtained in printed or electronic formats.

1.6 Inspection, transport and storage

Check the shipping and device packaging for transport damage and scope of delivery. In the event of complaints, the company must be notified immediately. Please use the contact form at the following address: <https://www.bender.de/en/service-support/take-back-of-old-devices/>.

When storing the devices, observe the information under Environment / EMC in the technical data.

1.7 Warranty and liability

Warranty and liability claims for personal injury and property damage are excluded in the case of:

- improper use of the device
- incorrect mounting, commissioning, operation and maintenance of the device
- Failure to observe the instructions in this operating manual regarding transport, commissioning, operation and maintenance of the device
- unauthorised changes to the device made by parties other than the manufacturer
- non-observance of technical data
- Repairs carried out incorrectly
- the use of accessories or spare parts that are not provided, approved or recommended by the manufacturer
- Catastrophes caused by external influences and force majeure
- Mounting and installation with device combinations not approved or recommended by the manufacturer

This operating manual and the enclosed safety instructions must be observed by all persons working with the device. Furthermore, the rules and regulations that apply for accident prevention at the place of use must be observed.

1.8 Disposal of Bender devices



Electrical and electronic equipment must not be disposed of with unsorted household waste but must be collected separately from household waste.

The symbol of a crossed-out wheeled bin indicates the requirement for separate collection.

Before returning a used device, used batteries and accumulators that are not enclosed within the device, as well as lamps that can be removed without damage, must be separated from the device and disposed of separately.

Please observe the applicable national regulations regarding the disposal of waste electrical and electronic equipment.

Waste electrical and electronic equipment may contain personal data. The end user is responsible for deleting this data prior to disposal.

Bender GmbH & Co. KG is registered in the Waste Electrical and Electronic Equipment Register (EAR) under WEEE number DE 43 124 402. To fulfill its legal take-back and disposal obligations, Bender has established appropriate return and disposal options. Information on available collection points and the process for returning waste electrical and electronic equipment can be found at: <https://www.bender.de/en/service-support/take-back-of-old-devices/>

1.9 Safety

If the device is used outside the Federal Republic of Germany, the applicable local standards and regulations must be complied with. In Europe, the European standard EN 50110 applies.



DANGER

Risk of fatal injury due to electric shock!

Touching live parts of the system carries the risk of:

- *Electrocution due to electric shock*
- *Damage to the electrical installation*
- *Destruction of the device*

Before installing the device and before working on its connections, make sure that the installation is de-energised.

Observe the rules for working on electrical systems.

1.10 Cybersecurity

- Information on Bender's CRA conformity: <https://www.bender.de/en/cert>
- To report cybersecurity vulnerabilities, contact: psirt@bender.de

CRA safety aspects during use

RS-485 interface	Communication via the RS-485 interface is not encrypted. • Protect the bus as much as possible from unauthorised access (e.g., through physical shielding or access control). • Please note the instructions for activating write protection in the Commissioning chapter.
NFC interface	With physical access to the device, parameters can be read and written using the Bender Connect app. A glass pane does not provide protection against unauthorised access. • Prevent physical access, for example by means of access control.
System access	COMTRAXX® devices, SCADA systems, and comparable systems may only be accessible to authorised persons.

2 Product description

2.1 Intended use

ISOMETER® in the isoMED527 series are used to monitor the insulation resistance R_F of a medical IT system with a rated voltage of AC 100...240 V. The maximum permissible system leakage capacitance C_g is 5 μ F. The load current and the temperature of the IT system transformer are also monitored.

Alarms and measured values are made available to other bus devices via the RS-485 interface. The use of special remote alarm indicator and test combinations is recommended for display and alarming.

After detecting an insulation fault, the isoMED527 supports insulation fault localization. Due to the new *isoNAP* measuring method, no locating current generator is required. The use of the EDS551 is recommended for localising the insulation fault.

In order to meet the requirements of the standards, customised parameter settings must be made on the equipment in order to adapt it to local equipment and operating conditions. Please heed the limits of the range of application indicated in the technical data.

The device is designed for applications involving low mechanical stress.

Do not make any unauthorised changes to the device. Only use spare parts and optional accessories sold or recommended by the manufacturer.

Caution: This equipment is not intended for use in residential environments and may not provide adequate protection to radio reception in such environments.

Intended use also includes

- the observation of all information in the manual and
- compliance with the test intervals in accordance with the relevant standards and operating rules.



The messages of the device must be perceptible even if it is installed in a control cabinet.

Any other use than that described in this manual is regarded as improper.

2.2 Device features

- Monitoring of the Insulation Resistance (R_F) in a medical IT system
- Preconfigured response value for the Insulation Resistance (R_F)
- Connection monitoring
- Voltage measurement per outer conductor to earth and total voltage with adjustable response values for overvoltage and undervoltage
- Functional earth monitoring with adjustable response value
- Measurement of the system leakage capacitance up to 5 μ F
- Alarm display via the LEDs AL1 and AL2
- Alarm output via alarm relay and/or RS-485 interface at a suitable point
- NC or NO current behaviour of the relays selectable
- Start-up, response and release delay adjustable
- NFC interface for parameterisation via Bender Connect App
- RS-485 interface with Bender Smart Connect protocol (BSC)
- Load current and temperature monitoring for IT system transformers

2.3 Product description

The ISOMETER® isoMED527 is an insulation monitoring device for monitoring medical IT systems. It continuously monitors the insulation resistance (R_F) as well as the load current and temperature of the IT system transformer.

The device has connections to the mains to be monitored, to the supply voltage and to sensors such as measuring current transformers and temperature sensors. Two relay outputs are also available for alarm forwarding. An RS-485 interface is used to communicate and parameterise the device via the Bender Smart Connect protocol (BSC).

Alarms are output via the LEDs on the front of the device, via the relay outputs and via the RS-485 interface. An NFC interface enables parameterisation via the Bender Connect app.

2.4 Functional description

The ISOMETER® isoMED527 monitors medical IT systems. It measures the insulation resistance R_F between the active conductors and the earth of a medical IT system as a preset measured value. Monitoring this measured value is required by law and meets the requirements of the relevant standards for medical IT systems. The preset response values are not below the limits specified in the standards.

As soon as a response value is undershot, the LEDs on the front of the device display the currently measured insulation resistance. The numerical display of the actual measured value and visual and acoustic signals when a response value is undershot are always also displayed on a connected remote alarm indicator and test unit. In addition, the load current and temperature of the IT system transformer are monitored. Alarms and measured values are made available to other bus participants via the RS-485 interface.

The device supports insulation fault localisation in combination with the EDS551. It does not require a test current generator due to the new *isoNAP* measuring method.

Depending on the configuration and if function module A is activated, impedance (Z), mains leakage capacitance (C), total hazard current (THC) and mains voltage can optionally be measured, displayed and used for additional warning messages. These functions are not required by standards and are not necessary for standard-compliant monitoring, but they provide a more complete picture of the condition of the medical IT system.

The measured and calculated parameters are assigned to defined alarms. These are defined:

- Insulation resistance
- Impedance
- System leakage capacity
- Total Hazard Current (THC)
- Overvoltage and undervoltage of the mains voltage
- Transformer overload
- Overtemperature of the transformer
- Functional earth monitoring

Furthermore, the messages and alarms are output via relays **K1** and **K2**. The relays can be configured by the user via the connected remote alarm indicator and test unit or via the interfaces.

2.4.1 Insulation fault R_F

Measured value determination and display

The insulation fault R_F is measured in *unearthed AC systems* and *AC systems superimposed with DC*. Measurements are taken in a range from 1 kΩ to 10 MΩ. The measured values are displayed in a range from 10 kΩ to 1000 kΩ via the value display LEDs.

Alarm threshold

The response value R_{an} is available in the device for the alarm limit value. The response value is set via the RS-485 interface or the Bender Connect app. Limit value for the alarm.
The alarms can be assigned to the relays **K1** and **K2**.

Device behaviour in the event of an insulation fault

The following diagram shows the device's behaviour:




Figure 2-1: Response behaviour Insulation resistance

Time period	Event	Reaction
1-2	The measured value falls below the response value R_{an} for a period shorter than the set response time t_{on} (plus device-specific operating time t_{a0}).	The device is not responding.
4-6	The measured value falls below the response value R_{an} for a period longer than the set response time t_{on} (plus t_{a0})	The alarm LED lights up and assigned relays are energised.
8-10	The measured value exceeds the response value R_{an} (plus hysteresis) for a period longer than the set response time t_{on} (plus t_{a0})	The alarm LED goes out and assigned relays are de-energised (from time segment 10). The alarm is deleted when the error memory is deactivated.



ADVICE
The time between the occurrence of an error and the corresponding message is a maximum of 5 seconds. The same applies to the correction of the error – here too, the time until feedback is received must not exceed 5 seconds.

2.4.2 IsoNAP measurement method

Identical to the previous methods, the *isoNAP* measurement method also superimposes a measurement voltage with a variable signal frequency on the unearthed IT system, measures it back, and evaluates it using a microcontroller.

In contrast to the *AMP* method, the capacitive network leakage current components do not act as a disturbance variable, but are part of the mathematical model that forms the basis of the evaluation. The insulation measurement is therefore not directly dependent on the decay of the dynamic current components. This enables significantly shorter measurement and feedback times. In addition, *isoNAP* provides measured values of the leakage capacitances in the system.

The *isoNAP* method can be used in AC and AC/DC networks. Like the network capacitance, the network voltage is also taken into account in the model, making the method even more robust against dynamic network voltages.

2.4.3 Connection monitoring L1/L2

The *connection monitoring L1/L2* continuously checks the impedance between the terminals **L1** and **L2** of the insulation monitoring device via the system to be monitored. If the impedance is too high, an alarm is triggered and indicated by the LEDs. The alarm can be assigned to the relays **K1** and **K2**.

2.4.4 Connection monitoring Functional Earth

The function *Connection monitoring Functional earth* continuously checks the resistance between the terminals **FE1** and **FE2**. If the resistance is too high, the alarm *Functional earth connection* is triggered and indicated by the LEDs. The alarm can be assigned to relays **K1** and **K2**.

2.4.5 Monitoring the IT system transformer

For temperature monitoring, the isoMED527 device analyses the resistance value of the temperature sensor. When the switching threshold of the bi-metal switch, PTC (4 kΩ) or the set temperature value (PT100) is reached, an overtemperature alarm is triggered.



ADVICE

To avoid overloading the transformer, the load current and temperature must always be monitored in combination. Please refer to the wiring diagram.

Before commissioning, check whether the connected temperature sensor matches the configuration set in the device menu. Incorrect assignment can lead to incorrect temperature values and malfunctions.



Temperature values in °C are only issued when using the PT100 temperature sensor.

2.4.6 Delay times t_b , t , t_{ae} , t_{on} and t_{off}

The times t_b , t , t_{ae} , t_{on} , t_{an} and t_{off} described below delay the output of alarms. They can be set in the menu of a connected remote alarm indicator and test combination and via the interfaces with the Bender Connect app and COMTRAXX®.

The following times are defined:

- Recovery time t_b**
 The recovery time t_b is the time the device needs to be ready for measurement after the supply voltage U_S has been connected. The value cannot be changed.
- Start-up delay t**
 After the supply voltage U_S has been connected, the measuring function is delayed by the set time t plus the recovery time t_b .
- Device-specific operating time t_{ae}**
 The response time of the device is defined by the time required by the device to record and utilize measured values (calculation). This time is not adjustable.
- Response delay t_{on}**
 The response delay t_{on} allows you to extend the response time of the device.
- Total response time t_{an}**
 If the defined limit values are violated, the device requires the (total) response time t_{an} to output the alarm. A set response delay t_{on} is added to the device-specific operating time t_{ae} and delays signalling:

$$\text{Total response time } t_{an} = t_{ae} + t_{on}$$
 The alarm is not reported if it is present for less than the defined response delay.
- Delay on release t_{off}**
 An alarm is maintained when the fault memory is deactivated until the measured value no longer violates the respective response value including hysteresis without interruption for the duration of the delay on release time.




Figure 2-2: Overview of time behaviour

2.4.7 Message assignments for the alarm relays

The following messages can be assigned to the alarm relays:

Function	State	Description
Relay mode	n/o principle n/c principle	• n/c n/c operation of the contacts. In fault-free condition, the relay is energised. • n/o n/o operation of the contacts. In fault-free condition, the relay is de-energised.
Test	on off	This parameter determines whether the relay is actuated during a test.
Alarm	on off	The relay switches when a selected response value is violated.
Device error	on off	The relay switches if a device error exists.
Connection fault	on off	The relay switches when there is a connection fault.

2.4.8 Self-test

After switching on the supply voltage, the device uses the self-test functions to permanently and automatically check all internal measuring functions, the components of the sequence control such as data and parameter memory as well as the connections to the IT system and to earth. You can also perform the self-test manually using the test button to check the function of the relays (depending on the configuration).

By pressing the **T/R** button (3...6 s) or executing the function *Test* on a connected remote alarm indicator and test combination or in the COMTRAXX® user interface, the device simulates an alarm status. In addition, the device performs a self-test at startup. If the alarm assignment is set, all LEDs light up and the outputs switch. The alarm messages are output via all device interfaces.

2.4.9 Factory setting

The factory settings are restored via remote alarm indicator and test combination or via the Bender Connect App. There are two options for restoring the factory setting:

- **Factory setting without interface parameters**

After activating all changed settings are reset to the factory settings. The settings for the RS-485 interface are retained.

- **Factory setting with interface parameters**

After activating all changed settings, including the settings for the RS-485 interface and the device address, are reset to the factory settings.

2.4.10 Device error

In the event of a device error, the status LED is lit up red. The error code can be queried via the RS-485 device interfaces.

2.4.11 Device identification

The device identification function is used to uniquely identify the device in the system. It can be triggered via the NFC or RS-485 interfaces.

After activation, the device switches to identification mode, in which all device LEDs light up one after the other. This cycle lasts 5 minutes and allows visual identification of the device that received the identification command.

The identification mode can be terminated at any time by briefly pressing the T/R button (approx. 1 second).

During identification, normal device functionality remains fully intact: alarm messages, measured values, and status information continue to be provided via the interfaces, relays, and - if activated - NFC. Only the LED display for error states is suppressed during identification mode.

3 Dimensions, mounting and connection



Only skilled persons are permitted to carry out the work necessary to install, put into service and run a device or system.



DANGER

Risk of fatal injury due to electric shock!


Touching live parts of the system carries the risk of:

- Risk of electrocution due to electric shock
- Damage to the electrical installation
- Destruction of the device

Before installing the device and before working on its connections, make sure that the installation has been de-energised. The rules for working on electrical systems must be observed.


3.1 Dimension Diagram

Device with plug-in terminals (push-in)



Dimensions in mm (inch)

3.2 Mounting and removal



Dimensions in mm (inch)

3.3 Connection

3.3.1 Connection properties



CAUTION

a) Risk of injury from sharp-edged terminals!

Risk of lacerations. Handle enclosure and terminals with care.



b) Property damage due to improper installation!

- Make sure that only one insulation monitoring device is connected in each conductively connected system. If several devices are connected, the device does not work and does not signal insulation faults. This can damage the installation.
- High load currents can result in damage to property and personal injury. Therefore, do not apply any load current to the terminals.
- The connecting lines to the system to be monitored must be designed as spur lines.
- Failure to connect the device as illustrated in the manual leads to deviating technical data and function restrictions.

c) Ensure disconnection from IT system!

When insulation or voltage tests are to be carried out, the device must be isolated from the system for the test period. Otherwise the device may be damaged.

3.3.2 Connections overview

		Terminal	Connection
top		A1, A2	Supply voltage
		11, 14, 12	Relay K1
		FE1, FE2	Seperate connections to functional earth (PE) (with sepearate lines)
		L1, L2	Connection to the system to be monitored
bottom		21, 24, 22	Relay K2
		•, •	Connection not in use
		Z1, Z2	Connection to temperature sensor
		A, B	RS-485 interface
		ON (R)	Termination RS-485 interface
		S1, S2	Connection to current transformer

3.3.3 Wiring diagram isoMED527




DANGER

Risk of electrocution due to electric shock!

Serious injuries with possible fatal consequences.

If the device is connected to a live IT system via terminals L1, L2, terminals FE1 and FE2 must not be disconnected from the protective earth conductor (PE).


Connect the device according to the wiring diagram:



CAUTION

Injuries, fires and property damage due to short circuits!

a) In accordance with the IEC 60364-4-43 standard, line protection must be provided for the connections to the supply voltage as follows:



- Fuses of 6 A are recommended.
- If supplied from an unearthed system, two back-up fuses must be used.
- If supplied from an earthed system, at least one back-up fuse must be used.

b) When connecting the terminals to the system to be monitored, you can dispense with protective devices if the line or cable is designed in such a way that the risk of a short circuit is kept to a minimum.

- Ensure short-circuit and earth-fault proof installation.



ADVICE

Rout the FE1 and FE2 cables separately.
Terminate the RS-485 bus at both ends.

4 Commissioning

Functional test prior to commissioning

Before commissioning, it is necessary to check that the ISOMETER® is properly connected. Carry out a functional test using a real earth fault via a suitable resistor.



ADVICE

If an incorrect measuring current transformer is set, errors and measurement deviations may occur. Example: If STW2 is used, it must also be set in the menu. Check in the device menu whether the correct measuring current transformer is configured.




ADVICE

If an incorrect temperature sensor is set, errors and measurement deviations may occur. Example: If the type PTC resistor acc. to DIN 44081 is used, it must also be set in the menu. Check in the device menu whether the correct temperature sensor is configured.

Enabling write protection

Activate the write protection of the RS-485 interface via COMTRAXX®, CP305, or the Bender Connect app. Activation prevents unauthorized changes to device settings via the RS-485 bus line, via a gateway, or on a remote alarm indicator and test combination.

5 **Operation**
5.1 **Control panel**



	Control panel
A	Status LED ON: Operating modes
B	Value display LEDs: 10, 50, 150, 1000 kΩ
C	Alarm LEDs: AL1 / AL2
D	T/R button: Test/Reset/NFC/Adress/Write protection

5.2 STATUS LED


Multicoloured display of various operating modes.



LED	Operating mode
GREEN	START PHASE Device booting after start NORMAL OPERATION Device in fault-free state
GREEN flashing	ADDRESS MODE
YELLOW	FAULT - Leakage capacitance C exceeded - Impedance fault Z underrun - Total Hazard Current THC exceeded
YELLOW flashing	CONNECTION FAULT - Connection fault system (L1/L2) - Connection fault earth (FE1/FE2) - Connection fault CT - Connection fault temperature sensor
RED	DEVICE ERROR Restart or replacement of the device required
RED flashing	NO RS-485 MASTER RS-485 master is not connected
BLUE + GREEN flashing	NFC ACTIVE

5.3 Measured value display LEDs

Measured value display of the insulation resistance.



LED	Operating status
[10 kΩ]	R_F value ≤ 10 kΩ
[50 kΩ]	R_F value ≤ 50 kΩ
[150 kΩ]	R_F value ≤ 150 kΩ
[1000 kΩ]	Lights up continuously for values > 150 kΩ

5.4 **ALARM LEDs**

Display of AL1 and AL2



LED	Operation state
AL1	YELLOW: The insulation resistance has fallen below the response value. YELLOW flashing: Overvoltage RED flashing: Overtemperature, Over current, Connection fault temperature sensor
AL2	YELLOW: The insulation resistance has fallen below the response value. YELLOW flashing: Undervoltage


5.5 **T/R button**

The T/R button activates different operating modes depending on how long it is pressed.



Mode	Operating time	Status LED
RESET	1...3 s	flashes yellow
TEST	3...6 s	flashes red
NFC	6...10 s	flashes blue
ADDR	10...15 s	flashes green
PROTECT	20...25 s	flashes violet


Overview



5.6 Function ADDR

Description

The function **ADDR** switches the device to address setting mode for the RS-485 address. The channel indication LEDs and the status LED indicate the device's address. The digits are represented using BCD code.



Addresses can only be entered within the valid address range. When there is no input for a period of 5 minutes, the device automatically exits the address setting mode. The device then uses the currently set RS-485 address.

Enter address

How to enter an address:

1. Press and hold the **T/R** button until status LED flashes green (10... 15 s).
– After the **T/R** button is released, the status LED lights red.
2. Set HUNDREDS digit. Press **T/R** button briefly until the desired value appears. Press and hold **T/R** button once (> 2 s) to confirm.
– After the **T/R** button is released, the status LED lights green.
3. Set TENS digit. Press **T/R** button briefly until the desired value appears. Press and hold **T/R** button once (> 2 s) to confirm.
– After the **T/R** button is released, the status LED lights blue.
4. Set UNITS digit. Press **T/R** button briefly until the desired value appears. Press and hold **T/R** button once (> 2 s) to confirm.
5. To exit the address setting mode, press and hold **T/R** button once (2 s).
– After the **T/R** button is released, the status LED lights green.

5.7 Function RESET

The function **RESET** resets stored alarm states and deactivates the limit hysteresis for this moment.

5.8 Function TEST

The function **TEST** simulates an alarm status for 5 seconds. During this period, the device has the following states:


- Display of the alarm value via the LEDs and the interface.
- The relay switches when the TEST signal assignment is active.
- The test status can be read out via the interface:

- 0 = no test
- 1 = internal test (triggered via T/R button)
- 2 = external test (triggered via Bender Smart Connect (BSC))
- For the duration of the test t_{on} and t_{off} are set to 0 s.

5.9 Function NFC

Press the **T/R** button for 6...10 seconds to activate or deactivate the NFC interface.

The NFC interface deactivates automatically after 5 minutes of inactivity.




Status indication of normal operation
with the NFC interface activated

5.10 Function PROTECT

The **PROTECT** button function changes the current activation status of the write protection if the **T/R** button is pressed for a period of 20...25 seconds.

- If the **T/R** button is pressed for at least 20 seconds, the status LED changes from steady green to flashing purple. This state remains for 5 seconds.
- If the **T/R** button is released during this period (5 seconds), the write access activation status changes from *enabled* to *disabled* or vice versa.



Status display of the PROTECT function

5.11 Menu settings isoMED527

Settings		
	Measuring point	
		Alarm settings
		1. Insulation resistance
		2. Impedance
		3. Total Hazard Current (THC)
		4. Start-up delay
		5. Memory
		Connection monitoring
		Coupling
		FE1/FE2 Response value
		Transformer current monitoring
		Transformer type
		Connection monitoring
		Response value
		Transformer temperature monitoring
		Temperature sensor
		System leakage capacitance
		Response value
		Response delay
		Reset delay
		Undervoltage
		Response value
		Response delay
		Reset delay
		Overvoltage
		Response value
		Response delay
		Reset delay

	Inputs/outputs	
		Relay 1
		Relay mode Message assignment • Test • Total Hazard Current (THC) • Impedance • Insulation resistance • Coupling • Capacity • Undervoltage • Overvoltage • Load current • CT connector • Device error • Temperature • Connection temperature sensor • Communication error
		Relay 2
		see Relay 1
	Interface	
		Bender Smart Connect
		• Address • Baud rate • Parity • Stopbits • Failure monitoring
		NFC
		NFC
		UPDATE
		Update via interface
	System	
		Factory setting
		Factory settings with interface Factory settings without interface Restore
		Write access
		Write access

Control	
	Test [Execute]
	Reset [Execute]
	Identify device [Execute]
Info	
	1. Manufacturer 2. Device 3. Application software 4. Bootloader 5. Bender Smart Connect
Licenses	
	• Acknowledgement of the "Temporary license expires" alarm with information on which function modules are deactivated in each case
Edit texts	
	Device
	Measuring values

6 Interfaces


6.1 RS-485 interface

Description

The RS-485 interface is galvanically isolated from the device electronics. It serves as a transmission medium for various protocols. It can be used to connect compatible devices to an RS-485 network. The specifications for the RS-485 interface are included in the technical data.


Connection

Use daisy chain structure




* The length of the bus cable depends on the number of devices, the transmission protocol, the cables used, and interference affecting the system. The following table provides guide values.

Cable length depending on the baud rate (empirical values)



Examples of RS-485 line structures



- 1 Master ● with termination
- 2 Slave ○ without termination
- 3 Slave ● with termination



ADVICE

For a stable RS-485 network, please note:

- Terminate the first and last device in the line.
- Assign each device address uniquely.
- Please refer to the technical data for information on the RS-485 interface.

Bender Smart Connect (BSC)

BSC bus: RS-485 interface with BSC protocol

The BSC protocol is an exclusive bus protocol for communication between Bender devices.

It offers functions such as

- Observer mode
- Acknowledge via interface
- Backup master functionality
- Forced alarming
- Auto detection
- Address collision resolution
- Identify device
- Start test

The BSC bus comprises Master, Observer and Slave roles. Further details can be found in the documentation for the device acting as the Master (e.g. CP305, D00425).



The device operates always as a slave. It cannot operate as a master or observer.

BSC and Modbus RTU can be used in parallel on the same bus. The BSC master can prompt Modbus RTU devices.

6.2 NFC (Near Field Communication)



The NFC interface can be used to transmit a previously configured device parameter setting directly to the device.



This function is available only via the Bender Connect App, which is available for iOS and Android.



In the Bender Connect App, the device must first be registered. The device-specific setting options are then displayed and can be configured. During data transmission, feedback is provided indicating whether the parameter configuration was successful.



Parameter settings can be transmitted to the device via the Bender Connect App by holding the smartphone close to the device:

- When the device is **unpowered**, parameter settings can be transmitted and are automatically activated once the device is connected to the power supply.
- When the device is **powered**, parameter configuration requires that the NFC interface is activated on the device beforehand.



6.2.1 Function modules

Optional function modules can be activated to extend the range of functions. The function modules can be ordered and activated directly when ordering the device or at a later date.

The isoMED527 is available in two versions:

- isoMED527-L-2 base unit
- isoMED527-L-2 with integrated function module A

The basic device can be retrofitted with the extended functions of function module A via the Bender Connect app or COMTRAXX® by activating the license. Alternatively, the device can be delivered with integrated function module A when ordering, so that the extended measuring functions are available ex works.

See also "Ordering details", page 40.

Base unit: Monitoring of the IT system

In its basic configuration, the isoMED527 the following functions:

- Monitoring of insulation resistance as a threshold alarm
- Monitoring transformer overload as a threshold alarm
- Monitoring transformer overtemperature as a threshold alarm
- Connection monitoring of the functional earth, IT system, load current transformer, temperature sensor
- Supported temperature sensors: PTC (according to DIN 44081) and bimetal switches

Function module A: Extended measurement values

The function module A adds the following functions:

- Monitoring of the IT system: insulation resistance, impedance, and total hazard current (THC) as measured value and threshold value alarm
- Voltage measurement per outer conductor to earth and total voltage with adjustable response values for overvoltage and undervoltage
- Connection monitoring of the functional earth with adjustable response value
- Connection monitoring IT system, load current transformer, temperature sensor
- Transformer load as measured value and alarm in amperes or in percent via interface
- Transformer overtemperature as alarm (and measured value for PT100)
- Supported temperature sensors selectable in the menu: PTC (acc. to DIN44081), PT100, bimetal switch

6.2.2 Subsequent activation of function modules

If function modules are not already configured ex works, they can also be purchased and installed at a later date.

1. Request license file

Additional functions are activated via license files. You can obtain the license file from the Bender service area.

Required information:

- Material product number of the device (MPN)
- Serial number (on the device or in the "Info" menu)

2. Download license file

After entering the data, the appropriate license file is provided. Save the file on your smartphone or PC.

3. Transfer and activation

There are two ways:

- a) **Web interface**(e.g. COMTRAXX devices):
Menu path: Settings > License management > Import license file
Upload and confirm file.
 - b) **Bender Connect App** (Recommended for mobile use):
Install the app from the App Store or Google Play. Connect to the device (via NFC). Import the license file in the Backup/Licenses menu. Activation is automatic, restart the device if necessary.
Activation may only be carried out by authorised specialist personnel.
4. **Check activation** Check the activated modules in the device under "Info" or "Licenses". To activate the functions, the device must be restarted.

Further links

Acquire licenses: <https://www.bender.de/en/service-support/licences/>

In case of problems: Contact Bender Service: <https://www.bender.de/en/service-support/fast-assistance/>

7 Technical data

7.1 Factory setting isoMED527

Response values / Alarms	
Response value Insulation resistance (R_{an})	50 k Ω
Response value Impedance (Z_{an})	off
Response value Total Hazard Current (THC)	off
Response value Capacity (C_{an})	off
Response value Loop resistance (R_{FE})	150 Ω
Response value Voltage measurement (U_{∞})	off

Time behaviour	
Start-up delay t	0 s
Response delay t_{on}	0 s
Delay on release t_{off}	0 s

Operation mode

Switching elements (Relaiys)	1	2
Test	on	on
Operation mode	Quiescent current (NC)	Quiescent current (NC)
Reporting assignment	Insulation fault R_F	Insulation fault R_F

RS-485 interface	
Address	100 + last two digits of the serial number
Protocol	Bender Smart Connect (BSC)
Baud rate	19,2 kBd
Parity	even
Stop bits	auto
Termination	off

Temperature sensor	
Temperature sensor	PTC (DIN 44081)
Response value Temperature sensor	4 k Ω

Connection of measuring current transformer	
CT type	STW2
Connection monitoring CT	on
Response value load current	7 A

7.2 Technical data

Isolation coordination acc. to IEC 61010-1/IEC 61010-2-30

Definitions

Measuring circuit (IC1)	L1, L2
Supply circuit (IC2)	A1, A2
Output circuits (IC3)	11, 12, 14
Output circuits (IC4)	21, 22, 24
Control circuit (IC5)	(FE1, FE2), (●, Z2, A, B), (●, Z1, S1, S2)
Rated voltage	240 V
Overvoltage category	III
Area of application	see "EMC", page 39

Rated impulse voltage

IC1/(IC2-5)	4 kV
IC2/(IC3-5)	4 kV
IC3/(IC4-5)	4 kV
IC4/IC5	4 kV

Rated insulation voltage

IC1/(IC2-5)	250 V
IC2/(IC3-5)	250 V
IC3/(IC4-5)	250 V
IC4/(IC5)	250 V
Pollution degree	2

Protective separation (reinforced insulation) between

IC1/(IC2-5)	overvoltage category III, 300 V
IC2/(IC3-5)	overvoltage category III, 300 V
IC3/(IC4-5)	overvoltage category III, 300 V
IC4/(IC5)	overvoltage category III, 300 V

Voltage test (routine test) according to IEC 61010-1

IC2/(IC1, IC3-5)	AC 2.2 kV
IC3/(IC1, IC4-5)	AC 2.2 kV
IC4/(IC1, IC5)	AC 2.2 kV

Supply voltage

Connection	A1, A2
Supply voltage ranged U_s	AC 100...240 V
Tolerance of U_s	-30...+15 %
Frequency range of U_s	50...60 Hz
Frequency range tolerance of U_s	±5 %
Power consumption	≤ 11 VA
Inrush current (< 5 ms)	< 20 A

Measuring circuit

Measuring voltage U_m	±24 V
Measuring current I_m at $R_F, Z_F = 0 \Omega$	≤ 300 μ A
Internal resistance R_i, Z_i	≥ 500 k Ω
Permissible extraneous DC voltage U_{tg}	≤ 276 V
Permissible system leakage capacitance C_g	≤ 5 μ F

IT system to be monitored

Nominal system voltage range U_n	AC 100...240 V
Tolerance of U_n	-30...+10 %
Frequency range F_n	50...60 Hz
Tolerance F_n	±5 %

Response values

Isolation resistance (R)	
Measuring range	1 k Ω ...1 M Ω
Response value R_{an}	50...500 k Ω
Step width	1 k Ω
Response uncertainty R_{an}	
up to 500 nF	±10 %, min. ±1 k Ω
up to 3 μ F	±20 %
up to 5 μ F	±40 %
Hysteresis R_{an}	10 %

Impedance (Z)

Measuring range	1 k Ω ...1 M Ω
Response value Z_{an}	off, 50...500 k Ω
Step width	1 k Ω
Response uncertainty Z_{an}	± 10 %, min. ± 1 k Ω
Hysteresis Z_{an}	10 %

Total Hazard Current (THC)

Measuring range	1...10 m
Response value THC_{main}	off, 1...5 mA
Step width	1 mA
Response uncertainty THC_{main}	± 10 %, min. ± 100 μ A
Hysteresis THC_{main}	10 %

Capacitance (C)

Measuring range	0...5 μ F
Response value C_e	off, 25 nF...5 μ F
Step width 1...5 μ F	100 nF
Response uncertainty C_e	± 10 %, min. ± 10 nF
Hysteresis C_e	10 %

Loop resistance (R_{FE})

Measuring range	150...1000 Ω
Response value R_{FE}	150...1000 Ω
Step width	10 Ω
Response uncertainty R_{FE}	± 20 %
Response time connection monitoring FE1	≤ 30 s
Hysteresis R_{FE}	10 %

Voltage monitoring ($U_{<>}$)

Measuring range	70...276 V
Response value $U_{<>}$	off, 70...276 V
Step width	1 V
Response uncertainty $U_{<>}$	± 2 %
Hysteresis $U_{<>}$	± 5 V

Time behaviour *

Response time t_{an} at $R_F = 0.5 \times R_{an}$ and $C_e=0.5 \mu F$ according to IEC 61557-8	$\leq 5 \text{ s}$
Start-up delay t_{start}	$0 \dots 1800 \text{ s}$
Response delay t_{on}	$0 \dots 1800 \text{ s}$
Delay on release t_{off}	$0 \dots 1800 \text{ s}$
Step width	1 s
Recovery time	$< 0.4 \text{ s}$

* Response times do not apply to total hazard current (THC)

Operation

Display	Status LED, ALARM LED, Channel LED
Button T/R	Functions: Reset, Test, NFC, Address setting, Write protection
DIP switch (Termination)	on, off

7.2.1 Connections

Connection with pluggable push-in terminals

Terminals	(A1, A2) (11, 14, 12) (21, 24, 22)
Connectivity	
rigid	$0.2 \dots 2.5 \text{ mm}^2$
flexible without plastic sleeve	$0.25 \dots 2.5 \text{ mm}^2$
flexible with plastic sleeve	$0.25 \dots 2.5 \text{ mm}^2$
Stripping length	10 mm
Conductor cross-section (AWG)	$24-12$
Terminals	(L1, L2), (FE1, FE2), (●, Z2, A, B), (●, Z1, S1, S2)
Connectivity	
rigid	$0.2 \dots 1.5 \text{ mm}^2$
flexible without plastic sleeve	$0.25 \dots 1.5 \text{ mm}^2$
flexible with plastic sleeve	$0.25 \dots 0.5 \text{ mm}^2$
Stripping length	9 mm
Conductor cross-section (AWG)	$24-16$

Connection with pluggable screw terminals

Terminals	(A1, A2) (11, 14, 12) (21, 24, 22)
Connectivity	
rigid	0.2...2.5 mm ²
flexible without plastic sleeve	0.2...2.5 mm ²
flexible with ferrule	0.25...2.5 mm ²
Stripping length	7 mm
Torque	0.5...0.6 Nm
Conductor cross-section (AWG)	24-12
Terminals	(L1, L2), (FE1, FE2), (●, Z2, A, B), (●, Z1, S1, S2)
Connectivity	
rigid	0.2...1.5 mm ²
flexible without plastic sleeve	0.25...1.5 mm ²
flexible with plastic sleeve	0.25...0,5 mm ²
Stripping length	7 mm
Torque	0.22...0.25 Nm
Conductor cross-section (AWG)	28-16

Switching elements

Number of switching elements	2 changeover contacts
Terminals	(11, 14, 12) (21, 24, 22)
Operating mode	n/c operation, n/o operation
Electrical life at rated conditions	10,000 switching cycles

Contact data acc. to IEC 60947-5-1

Utilisation category	AC-13 / AC-14 / DC-12 / DC-12 / DC-12 / DC-12
Rated operational voltage	240 V / 240 V / 24 V / 48 V / 110 V / 220 V
Rated operational current	2 A / 2 A / 1 A / 0.5 A / 0.2 A / 0.1 A
Minimum contact rating ^{*)}	10 mA at AC/DC ≥ 10 V

^{*)} Refers to relays that were not operated with high contact currents.

Interfaces

RS-485 interface

Connection terminal	A, B
Protocol	Bender Smart Connect (BSC)
Baudrate	protocol-dependent, max. 115.2 kbit/s
Parity	even, no, odd
Stop bits	1/ 2/ auto
Cable length (at 19.2 kbit/s)	≤ 900 m
Cabletype: twisted pair, shield connected to PE on one side	CAT6/CAT7 (min. AWG23) alternatively: J-Y(St)Y min 2 x 0.8
Terminating resistor (internal)	120 Ω (0.25 W)
Device address, Bender Smart Connect	1...247

NFC interface

Frequency	13.56 MHz
Transmission power (modulating; at a distance of 0 m, for example) ¹⁾	0 W

- ¹⁾
- When used as intended, the device does not emit any radio waves.
 - EMC interference can cause communication failures in the NFC interface.

Connection CT

Connection terminal	S1, S2
Types	off, STW2, STW3, STW4
Max. cable length (recommended)	10 m
Response value	off, 1...50 A, 10...100 A, 10...200 A
Response time overload (from 50% to 120%)	≤ 5 s
Response time for converter monitoring	≤ 5 s
Response tolerance	±5 %
Hysteresis	4 %

Connection temperature measurement

Terminal	Z1, Z2
Maximum length of connection cable (recommended)	10 m
PTC resistor acc. to DIN 44081	
Maximum number for connection	6
Response value	4 kΩ
Release value	1.6 kΩ
Response uncertainty	±10 %
Response time for connection monitoring	< 5 s
PT100 (no series or parallel connections)	
Response value	50...150 °C
Hysteresis	10 %
Response uncertainty	±5 %
Response time for connection monitoring	< 5 s
Bi-metal switch	
Operating mode	SPST-NC (normally closed)
Set point direction	rising (when exceeding)

Environment/EMC

EMC	IEC 61326-2-4
Maximum operating altitude	2000 m AMSL

Ambient temperatures

Operating temperature	-25...+55 °C
Transport	-40...+85 °C
Long-term storage	-40...+70 °C

Classification of climatic conditions acc. to IEC 60721 (related to temperature and relative humidity)

Stationary use (IEC 60721-3-3)	3K22
Transport (IEC 60721-3-2)	2K11
Long-term storage (IEC 60721-3-1)	1K22

Classification of mechanical conditions acc. to IEC 60721

Stationary use (IEC 60721-3-3)	3M11
Transport (IEC 60721-3-2)	2M4
Long-term storage (IEC 60721-3-1)	1M12

Other

Operating mode	Continuous operation
Mounting	Cooling slots must be ventilated vertically
Degree of protection (DIN EN 60529)	IP20
Enclosure material	Polycarbonate
DIN rail mounting	TS35 acc. to IEC 60715
Flammability class	UL 94 V-0
Documentation number	D00521
Weight	≤ 130 g

7.3 Standards and approvals

Standards

The isoMED527series complies in accordance with the following standards.

- IEC 61557-8
- IEC 60364-7-710

Approvals



Open-source software

For a list of the open-source software used see our [Homepage](#).

Declarations of conformity

Bender GmbH & Co. KG hereby declares that the device covered by the Radio Equipment Directive complies with Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following internet address:

- [EU-Declaration of conformity isoMED527](#)

7.4 Ordering details

Type	Supply voltage U_s	Art. No.
isoMED527-L-2	AC 100...240 V	B81625521
isoMED527-L-2 incl. functional module A	AC 100...240 V	B81625524

Accessories

Type	Description	Art. No.
CP305-IO	Remote alarm indicator	B95100051
LIM/IMD plug kit 2DU screw	Optional	B80609202
LIM/IMD plug kit 2DU plug-in	Included in delivery	B80609203

Type	Description	Art. No.
STW2 Transformer Load Monitoring Device	1...50 A	B942709
STW3 Transformer Load Monitoring Device	10...100 A	B98021000
STW4 Transformer Load Monitoring Device	10...200 A	B98021001

7.5 Change log

Date	Version	Software version	Changes
06/2026	00		NEW document



Bender GmbH & Co. KG

Londorfer Straße 65
35305 Grünberg
Germany

Tel.: +49 6401 807-0
info@bender.de
www.bender.de

All rights reserved.
Reprinting and duplicating only with
permission of the publisher.



© Bender GmbH & Co. KG, Germany
Subject to change!
The specified standards take into
account the edition valid until 08.2026
unless otherwise indicated.